

GATEMASTER

Bolt on locks with forend

Specification Sheet
No.147

- Deadlock, latch deadlock and keylatch versions of this lock available
- These locks can be fitted into a mortise on the edge of a gate or door. They are ideal for use on wooden gates where the long 30mm throw gives plenty of tolerance.
- Very easy to fit

Product Options

Three locks available,

- SBD1601F** Deadlock with forend plate
- SBLD1601F** Latch deadlock with forend plate
- SBKL1601F** Keylatch with forend plate

Installation

1. Mortise the timber to take the lockcase.
Lockcase measurements are:
Height x Width x Depth
110mm x 30mm x 98mm
2. Cut holes for the eurocylinder, 37.5mm back from the front of the lock. For the latch deadlock also cut holes for the handles 70mm from the front of the lock
3. Install the lock using the four screw holes in the forend plate

Maintenance

Every 2 months - Lubricate latchbolt with light oil.
Annually – Dismantle lock and spray mechanism inside with light oil



SBD1601F



SBKL1601F